



Setting the Clock

1. Plug in the unit.
The display will flash AM 12:00.
2. To set the hour, while holding down the **CLOCK** button, press the **TIME SET H** button. When the correct hour appears in the display, release the **CLOCK** button.
3. To set the minute, while holding down the **CLOCK** button, press the **TIME SET M** button. When the correct minute appears in the display, release the **CLOCK** button. The clock will begin to operate.

- Each press on the **TIME SET H** or **TIME SET M** button advances the displayed number by one.
- The minute digits advance to "00" after "59". The hour digits do not advance by pressing the **TIME SET M** button.
- To adjust the time exactly to the second, release the **TIME SET H** or **TIME SET M** button simultaneously with the radio or telephone time signal.

Playing the Radio

1. Set the **ALARM** selector to **RADIO ON** to turn on the radio and adjust **VOL** (volume).
2. Select **FM** or **AM** and tune in a station using the **TUNING** dial.

- To turn off the radio, set the **ALARM** selector to **OFF**.
- To improve radio reception:
FM: Since the antenna is encased in the AC power cord, extend the cord to improve FM reception.
AM: Rotate the unit horizontally for optimum reception. A ferrite bar antenna is built into the unit.

Setting the Alarm

To set the radio alarm, first tune in a station and adjust the volume.

1. To set the hour for alarm, while holding down the **ALARM** button, press the **TIME SET H** button. When the desired hour appears in the display, release the **ALARM** button.
2. To set the minute for alarm, while holding down the **ALARM** button, press the **TIME SET M** button. When the desired minute appears in the display, release the **ALARM** button.
3. Set the **ALARM** selector to **RADIO** or **BUZZER**. The alarm will come on at the preset time and automatically turn itself off after 119 minutes.

- To shut off the alarm, press **REPEAT ALARM/SLEEP OFF**.
The alarm will come on at the preset time the next day.
- To cancel either alarm, set the **ALARM** selector to **OFF**.
- To doze a few more minutes, press **REPEAT ALARM/SLEEP OFF**.
The alarm will shut off, but will come on again after about nine minutes. You can repeat this process as many times as you like.
- To adjust the radio alarm volume, turn **VOL**. The buzzer volume is fixed.
- To check the preset time, press **ALARM**.

Setting the Sleep Timer

Enjoy falling asleep to the radio using the built-in sleep timer that shuts off the radio automatically at a preset time.

1. While listening to the radio, set the **ALARM** selector to **OFF**.
2. Press **SLEEP**.
The radio turns on. It will go off after 59 minutes.

- To turn off the radio before the preset time, press **REPEAT ALARM/SLEEP OFF**.
- Every time you press **SLEEP**, the sleep timer is reset to 59 minutes.
- When you set the **ALARM** selector to **RADIO** or **BUZZER**, if the preset alarm time comes while the sleep timer is operating, the radio or buzzer sounds depending on which you set.

Precautions

- Operate the unit on the power sources specified in "Specifications".
- To disconnect the power cord, pull it out by the plug, not by the cord.
- Do not place the unit on surfaces (rugs, blankets, etc.) or near materials (curtains, draperies) that block the ventilation holes.
- Should anything fall into the unit, unplug the unit and have it checked by qualified personnel before operating it further.
- To clean the casing, use a soft cloth dampened with a mild detergent solution.

Battery Warning

When the unit will be left unplugged for a long time, remove the battery to avoid undue battery discharge and damage to the unit from battery leakage.

If you have any questions or problems concerning your unit, please consult your nearest Sony dealer.

Put switch to off

Specifications

Frequency range
FM: 87.6 - 108 MHz
AM: 530 - 1710 kHz

Speaker
Approx. 6.5 cm (2 1/4 inches) dia.

Power output
100 mW (at 10% harmonic distortion)

Power requirements
120 V AC, 60 Hz
For the power back-up function: 9 V DC, one 6F22 battery

Battery life
Approx. 80 hours, using Sony battery S-3006PUL

Dimensions
Approx. 181.5 x 60 x 144 mm (w/h/d)
(7 1/4 x 2 3/4 x 5 3/4 inches) incl. projecting parts and controls

Mass
Approx. 570 g (1 lb 4 oz) net incl. battery

Design and specifications are subject to change without notice.

